

# FCB-H11

## Basis Sony FCB-H11



<p><b>FCB-H11 HD-Analog</b> Basis FCB-H11</p> 		<p><b>Output Signal</b> HD Analogue Component Y/Pb/Pr HD Analogue Component Y/Pb/Pr SD Y/C SD FBAS</p> 	<p><b>Order Code</b> 20028007</p>
<p><b>FCB-H11 HDMI</b> Basis FCB-H11</p> 		<p><b>Output Signal</b> HDMI SD Y/C SD FBAS</p> 	<p><b>Order Code</b> 20028008</p>
<p><b>FCB-H11 HD-SDI/HD-A</b> Basis FCB-H11</p> 		<p><b>Output Signal</b> HD SDI HD Analogue Component Y/Pb/Pr SD Y/C SD FBAS</p> 	<p><b>Order Code</b> 20028009</p>
<p><b>FCB-H11 HD-SDI</b> Basis FCB-H11</p> 		<p><b>Output Signal</b> HD SDI SD FBAS</p> 	<p><b>Order Code</b> 20028006</p>
<p><b>FCB-H11 DVI</b> Basis FCB-H11</p> 		<p><b>Output Signal</b> DVI SD FBAS</p> 	<p><b>Order Code</b> 20028012</p>
<p><b>FCB-H11 HD-SDI-FO</b> Basis FCB-H11</p> 		<p><b>Output Signal</b> HD SDI HD DSI Fiber Optics SD FBAS</p> 	<p><b>Order Code</b> 20028014</p>
<p><b>Remote Control H11</b> for FCB-H11</p>		<p><b>RS232 Interface</b></p> <p>Cable RC 2m Cable RC 5m Cable RC 10m Cable RC 15m</p>	<p><b>Order Code</b> 30055128</p> <p>30039103 30039102 30039104 30039105</p>